

# MTG 6000 Instructions: Uploading New Program

---

1. Turn the **POWER** switch on the back of player to the **OFF** position.
2. Plug the **USB** cable into the **USB** port on the back of your player.
3. Plug the other end of the cable into the **USB** port on your computer.
4. Turn the **POWER** switch to the **ON** position (LCD will show an icon of a computer and a memory card with the word “**READY.**”)
5. Go to “**My Computer**” and double click on the player (shown as “**Removable Media**” on your PC.)
6. Delete the old program.
7. Locate and select any **MP3** or **WMA** audio file(s) or files(s) of your on-hold audio.
8. Copy the file.
9. Paste the files to the player.
10. Turn the **POWER** switch on the back of player to the **OFF** position.
11. Remove the **USB** cable and turn the player back to the **ON** position.



1-888-353-6745